TA Control

Application for Apple iPhone

User Manual

Version 0.9 ***08/2012***

T+A elektroakustik GmbH & Co. KG

Contents

Page

General information
- Functions 4
- Hard- and software 4
- Creating a connection 4

Operating internal sources
- Screen sub-divisions 5
- Display 6
- Source select 6
- Volume and tone settings 6
- Control 6

Operating external sources
- Screen sub-divisions 7
- External source select 8
- Display 8
- Control 8

UPnP Control
- Screen sub-divisions 9
- Connecting the device 11
- Search server 11
- Control 11
- Playlists 12

Internet radio
- Screen sub-divisions 13
- General information 14
- Internet radio search 14
- Favourites 14
- Control 14

Trouble shooting 15

iPad, iPhone und iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

General information

Functions

If you have **T+A** devices - such as a Music Receiver - connected to your home network, the **TA Control App** provides a convenient means of operating them from a Tablet PC (iPhone).
The App controls all the functions of the device in the same way as a normal remote control handset. Information and screen content is relayed back from the device to the App, which means that it is possible to operate the equipment even when there is no visual contact with the system, e.g. from an adjacent room.
The method of using the App to control device functions is almost identical to the conventional method using the infra-red remote. In general terms all the buttons displayed in the App have the same functions as the corresponding buttons on the remote control handset.
The App also incorporates control of a UPnP server, including the creation and management of playlists.
This function offers a very convenient means of accessing a UPnP server which is present on the local network (LAN), making it possible to play the music stored on the server. It is also possible to create, manage and save playlists.
The system also provides a convenient method of selecting Internet radio services. In this case the App directly accesses the station lists of vTuner, and plays the selected radio service via the selected **T+A** device.
An additional advantage is that stations to which you frequently listen can be saved in Favourites lists.

Hard- and software

If you wish to be able to use the App in conjunction with your **T+A** device you must ensure that compatible firmware is installed on your device.
See also the Chapter entitled '**Trouble shooting**'.
The App requires the operating system iOS 5.0 or higher.

Creating a connection

A connection with the **T+A** device must be created before the App can be used to operate the equipment. You will find a description of this procedure in the Chapter entitled '**UPnP Control**' on Page 11.

Operating internal sources

(e.g. Radio and Disc)

① Source select

This is where you select the desired listening source.

② Display

The piece of music currently playing is displayed here, together with device status information.

③ Control

All the important control elements, such as cursor buttons, Start, Stop, numeric keypad etc. are arranged in this area.

④ Volume

The control elements for volume, muting and tone settings are found in this area.

Disc

Radio



Operating internal sources

(e.g. Radio and Disc)

Connecting the device

See the Chapter entitled '***UPnP Control***' on page 11.

Display

The screen displays the most important screen content of the connected device. Additional symbols such as Repeat and Shuffle are shown to the left of the screen.

ⓘ The screen displays and symbols vary according to the currently active function (Disc, Radio, etc.) and the type of music being played.

Source select

The listening source is selected by briefly pressing the desired source displayed in the lower part of the screen ①. The view switches to the corresponding source. See the next Chapter (P. 7) for information on selecting external sources.

ⓘ The available sources are only displayed when the App is connected to the device.

Volume and tone settings

The control elements for volume control, muting and tone settings are always arranged below the display ②, regardless of the selected source.

To adjust the Volume press the button and rotate the appearing volume knob. The currently set volume is indicated by the blue bar graph around the knob.

ⓘ Not all devices support the bar graph.

The button calls up the tone control menu and superimposes the needed control buttons.

The button switches the loudspeakers / the output on and off (mute switch).

Control

In general terms the button symbols used in the App correspond to those of the remote control handset supplied with the device. The device is operated in accordance with the instructions supplied with the equipment.

Adjustments, such as the device's tone controls, can be carried out in the usual way, since this display content is also transferred.

Operating external sources

(e.g. Bluetooth, Digital and Analogue inputs)

① Source select

You can switch to source select for the external sources (if present) here.

② Display

The currently selected source is displayed here.

③ External sources

Here you can select the external sources available for the device.

④ Volume

The control elements for volume, muting and tone settings are found in this area.



Operating external sources

(e.g. Bluetooth, Digital and Analogue inputs)

External source select

To select an external source, briefly press the

button in the screen area ①, and then select the desired external source in the screen area ③ with a brief press. The device now switches to the selected source.

Display

The screen displays the currently selected external source. If this is connected to a digital input, the sampling frequency is also shown.

Control

The control elements for volume, muting and tone settings are arranged in screen area ④.

The method of operation is described in the Chapter entitled '***Operating internal sources***' on page 6.

UPnP Control

Screen sub-divisions

① Source select

The desired listening source can be selected here.

② Functions

In this area you can switch over between the different functions and views.

③ Browser

The Browser window enables you to search through the storage facilities available on the network, e.g. NAS servers.

Browser view



Playlist view



UPnP Control

Screen sub-divisions

④ **Control**

All the important control elements, e.g. volume, start, stop etc. are arranged in this area.

⑤ **Display**

The piece of music currently playing is displayed here, together with device status information.

⑥ **Volume**

The control elements for volume, and tone settings are displayed as a pop up window in this area.

At normal playback a cover image is displayed here if present.

A

Play view



Pop up window for volume and tone settings



UPnP Control

Operation

Connecting the device

Briefly press the UPnP Control source in the bottom line ①, then press the Renderer button in the screen area ②. A window is now superimposed showing all the T+A devices available on the network (renderers). Briefly press on the device which is to be connected to the App. After a brief interval the device is connected, and all the sources of the connected device appear in the line ①.

ⓘ The screen only displays those sources which are actually present for the connected device.

Search server

The Browser window ③ provides an overview of all storage devices (servers, etc.) available on the network. The folders can be scrolled with a finger, and opened with a brief press. Briefly pressing the Back button returns you to the previous folder level.

Playable music tracks are indicated by a symbol, and can be started by briefly pressing on them.

If the symbol features a red Plus symbol , the tracks can be added to a playlist. If the symbol features a blue Play symbol , then that track can be played.

Use the Play and Add button to switch the functions.

Filter function

The Filter function is located in the top line of the Browser window. This function is used to filter the folders according to the content you require. To use the filter, press briefly in the window and enter the desired term using the keypad; finally confirm your choice with 'Done'. The list will now be filtered in accordance with the term you have entered.

Control

All the control elements for controlling playback are arranged in the screen area ④.

ⓘ The method of adjusting volume, muting and tone settings is described in the Chapter entitled 'Operating the internal sources' on page 6.

Playback control

Playback can be controlled either when playing from the browser or from playlists.

Playlists

The playlists are displayed in the browser window ③. The Playlist appears if the Playlist button in screen area ② is pressed.

Creating a playlist

The first step in creating a playlist is briefly to press the Browser button in the window area ②, then briefly press the Add button above the browser window ③. All the music tracks in the Browser window now feature a red Plus symbol . Briefly pressing the desired track adds it to the playlist.

ⓘ Each list can store a maximum of 100 tracks.

Erasing tracks from a playlist

To erase a track first change to the playlist view and then briefly press the Edit button above the playlist. The entries now feature a ⊖ symbol. Briefly press the symbol of the track to be erased, then erase it by briefly pressing the Delete button. Briefly pressing the Edit button again quits the Edit function.

The whole playlist can be cleared by a brief press on the Clear button.

Changing the track sequence

To change the sequence of tracks, first briefly press the Edit button above the playlist. To move a track, hold the 1 symbol, move it to the desired position, then release it again.

Saving a playlist

To save a new playlist, briefly press the Save button. An input window now appears in which you can enter the name of the playlist. Press in the text field, enter the name, and confirm you choice with 'Done' on the keypad; the playlist is now saved.

Calling up a playlist

To call up a saved playlist briefly press the Load button in the Playlist view: a window now opens containing all the saved lists. Select the desired playlist with a brief press. The window closes, and the playlist is displayed in the screen area ③.

Erasing a playlist

To erase a saved list, briefly press the Load button in the Playlist view. A window opens showing all the saved lists. Locate the list you wish to erase, wipe over it to right or left with a finger, then briefly press the Delete button to erase it.

Playing a playlist

To play a track in a playlist, simply press briefly on the desired track in the list. When the selected track ends, the next track in the list is played, etc. Playback ceases at the end of the list unless you have switched on the Repeat function.

The ▷ symbol indicates the currently active track.

Internet radio

Screen sub-division



① Source select

Here you can select the desired listening source.

② Display

The current Internet radio stream and device status information are displayed at this point.

③ Browser

It is possible to navigate conveniently through the lists of Internet radio stations in the Browser window.

④ Volume

The control elements for volume, muting and tone settings are found in this area.

⑤ Favourites

The buttons for managing Favourites are arranged in this part of the screen.

Internet radio

Operation

General information

The App's Internet radio function is the device's integral Streaming Client function. However, this can be operated even more conveniently using Browser navigation than was previously possible using the remote control handset.

ⓘ For the Internet radio function the connected T+A device and the iPad must have access to an Internet connection.

Internet radio search

The Internet radio content is displayed in the Browser window ③.

You can scroll through the folders with a finger, and open them with a brief press. Pressing the Back button returns you to the previous folder level.

Internet radio stations are indicated by the symbol, and can be started with a brief press.

Filter function

The Filter function is located in the top line of the Browser window. This function is used to filter the folders according to the content you require. To use the filter, briefly press in the window and enter the desired term using the keypad; finally confirm your choice with 'Done'. The list will now be filtered in accordance with the term you have entered.

Favourites

For faster access, the App can be used to save preferred Internet radio stations in the '**My Favourites**' folder. Since the data is saved at the vTuner Internet radio service, rather than locally in the App, the stations stored there can also be called up subsequently on the device itself.
The buttons for managing Favourites are arranged in the lower part of the screen ⑤.

Adding Favourites

To save a selected station, briefly press the add to My Favorites button.

Calling up the 'My Favourites' folder

To call up the '**My Favourites**' folder, briefly press the go to My Favorites button.

Erasing Favourites

To remove a station from the list, first call up the '**My Favourites**' folder by briefly pressing the go to My Favorites button. Select the station to be erased by briefly pressing it, then press the remove from Favorites button to erase it.

Control

The control elements for volume, muting and tone settings are arranged in the screen area ④. The method of operation is described in the Chapter entitled ***'Operating the internal sources'*** on page 6.

Trouble shooting

Many problems have a simple cause and a correspondingly simple solution. The following section describes a few difficulties you may encounter, and the measures you need to take to cure them.

The device cannot be connected to the App

The following error message appears:

'*Device Firmware does not support TA Control*'

Cause:

T+A devices which are to be controlled using the App require device software (firmware) which is prepared for the App. You can find out whether compatible firmware is available for your device by visiting our website at:
www.ta-hifi.com/app.

Remedy:

Install firmware prepared for the App on your device.
Information regarding firmware updates can be found on our website at
www.ta-hifi.com/support

The volume display bar graph does not appear

Cause:

The device is not designed to send the volume value to the App.

Remedy:

If the device cannot transfer a volume value, then unfortunately the bar graph cannot be displayed.

Playback of Internet radio stations not possible

Cause:

The device, the iPhone or both are connected to the local network, but not to the Internet.

Remedy:

Connect the device **and** the iPhone to the Internet.

Playback is interrupted

Cause:

The App was minimised during playback.

Remedy:

Do not close the App until playback has finished.

We reserve the right to alter specifications..

9103 - 0472

T+A elektroakustik GmbH & Co. KG

32052 Herford | Planckstr. 9 – 11 | Tel. +49 (0)5221 – 76760 | www.ta-hifi.com

Deutschland * Germany * Allemagne